


HOW TO ASSEMBLE A ROCKING TOY BY NOBSI




Video instructions of assembling the rocking toy:


mynobsi.com/assembling




1. Take out the box of slats.




2. Cut the tapes on the box.




3. Take out the slats and assembly kit.



4. Fold the edges away from one side of the box.



NB! Push the assembly key to the bottom of the screw head.
Use gloves for a better experience.



5. Lay the box vertically under the side detail. Hold in place with your hand and fix the first slat into the **socket** with the screw. **Tighten the screw all the way**.



6. Hold with your hand and fix the middle slat in place with the screw.


Tighten the screw all the way.

7. Remove the box and fix the last slat in place with the screw.


Tighten the screw all the way.



HOW TO ASSEMBLE A ROCKING TOY BY NOBSI









8. Place the rest of the slats in the sockets and fix them with screws.

9. Lay your work as pictured.

10. Put the other side detail on top of the slats.








12. After all the slats are in the sockets tighten the screws all the way.



13. Awesome rocking toy is ready!

* You may use cordless drill with the headpiece HEX 3



Warnings:

- Not suitable for children under 1 years.
- Maximum carrying capacity is 50 kg.
- To be used under the direct supervision of an adult.
- Only for domestic use.

More info:

https://mynobsi.com Tel: 00372 51 87 825 Email: info@mynobsi.com